


Joining rail alignment fixture



The joining rail alignment fixture AT / AK is used during installation of joined rails in order to precisely align the rails with each other. Joining rail alignment fixture AT for joined T-and U-rails. Joining rail alignment fixture AK for K-rails.




General Data



Alignment Fixture AT
for T- and U-rails



Alignment Fixture AK
for K-rail



Designation	Size	Compatible with
AT18	18	T- and U-rails
AT28	28	T- and U-rails
AT43	43	T- and U-rails
AT63	63	T- and U-rails
AK43	43	K-rail
AK63	63	K-rail