

Belt Conveyor

BF40E IK - 1200 - 1000 - 38 R T L F 5 B - 1 1 0 0 0 0

Size

BF40
BF80

Type

E = End
M = Middle

Knife edge

IK = In Feed
OK = Out Feed
DK = Double / Both

Width

Length

c/c roller

Speed

Motor side

R = Right
L = Left

Belt type

For further information see "Belt" in product range on website.

Conveyor guides left

0 = No guides
1 = Bent side
2 = Side support alu
3 = Adj. side support

Conveyor guides right

0 = No guides
1 = Bent side
2 = Side support alu
3 = Adj. side support

Belt profiles

0 = No option
1 = Quadratic profiles
2 = Thin profiles
3 = Wide angled profiles
4 = Side walls

Tracking guides

0 = None
1 = K6 (6x4x4)
2 = Kn8 (8x5x5)
3 = Kn10 (10x6x6)

Stand

0 = No
1 = Yes

Motor

BF40:	BF80:
0 = No motor	0 = No motor
1 = MS63A-4	5 = MS71A-4
2 = MS63B-4	6 = MS71B-4
3 = MS63C-4	7 = MS80A-4
4 = ML63B-4	8 = MS63B-4 B5

Stand

BS 40 - XXXX - XXXX HXXX - X - XXXX 0 0 02

Profiles
 40 = 40x40 Semi Profiles
 80 = 40x80 Semi Profiles

Width

Length

Height

No. of sections

Profile length (l1)

Attachments
 1 = Corner Brackets
 2 = T-Plate

Foot plate
 0 = Without foot plate
 1 = Without foot plate

Floor attachments
 01 = Swivel castor with total lock and bolt hole
 02 = Swivel castor with bolt hole
 03 = L-Based Foot
 04 = Angle Foot A1, adjustable
 05 = Adjustable Foot Ø 39 M8 / L 65
 06 = Adjustable Foot Ø 39 M10 / L 65
 07 = Adjustable Foot Ø 79 M8 PSD / L 71
 08 = Adjustable Foot Ø 79 M10 PSD / L 71
 09 = Adjustable Foot Ø 79 M12 PSD / L 71
 10 = Adjustable Foot Ø 79 M16 SVD / L 161
 11 = Adjustable Foot Ø 79 M10 SVDB / L 71
 12 = Adjustable Foot Ø 79 M12 SVDB / L 151
 13 = Adjustable Foot Ø 79 M16 SVDB / L 161

Note:
 All our conveyors are skillfully adjusted and tested on our factory floor before delivery. After delivery and placement however we cannot guarantee perfect running and strongly recommend final adjustments to be made. Please see the documentation provided with the conveyor for more information on how best to do this. Note that most tracking problems occur from uneven assembly of conveyor bases or flooring and that belt tension should be maintained when adjustments made. Motors are not individually tested and not assembled to the unit during transport.