## **ST Stainless Dustproof Tape**

Stainless steel ST dustproof tape improves rail face sealing and works in conjunction with guide block seals.

Conventional plastic plugs do not offer the same improved sealing performance.


## Installation of ST tape:

- 1. After assembling a rail to the bed, clean the surface of the rail and remove any oil.
- 2. Attach the ST tape slowly over the rail length to within 2 or 3 mm from each end of the rail.
- 3. After attachment to the rail, apply pressure with dry cloth 3 or 4 times along the length of the rail to release encapsulated epoxy. Tape should be applied 4 to 6 hours prior to use to allow initial bonding.

Note: It is strongly recommended to wear safety gloves, the edge of this tape is sharp and can cut as you attach it to the rail.



## **Dimensions**



Designation	w	t
SBI15ST	11	0,1
SBI20ST	15	0.1
SBI25ST	17	0.1
SBI30ST	21	0.1
SBI35ST	27	0.1
SBI45ST	37	0.1
SBI55ST	43	0.1
SBI65ST	51	0.1